


## **How to Measure**

Please contact us toll free at 855-318-5022 or orders@bigbluewindow.com for a additional help.

## **Surround Grille Measurements**



## **How to Measure for Surround Grilles**

- To measure **Daylight Opening (DLO)**, measure the visible glass, from stop to stop.
- To measure the **Tip-to-Tip** dimension, measure the longest part of the surround (perimeter) portion of the grille, on the top of the profile (the portion that faces outward from the glass).
- To measure the **Underneath** dimension, measure the shortest part of the surround (perimeter) of the grille, on the bottom of the profile (the portion that touches the glass).