




# How to Measure

Please contact us toll free at  
855-318-5022 or  
orders@bigbluwindow.com  
for a additional help.



## How to Measure for Locks

- Measure from the edge of the visible glass to the center of each lock.
- Measure the height of the lock from the tallest point to its resting place on the sash.
- Measure the lock width to the outermost points.